

## MP346 Fitting Instructions Double Tow Bar Step

Complete with electrical socket mounting plate extension allowing electrical sockets to be mounted below the tow ball and tow bar step.

1. Remove tow ball and electrical sockets from the tow bar.
2. Fit the Tow Bar Step and socket extension plate (if required) between tow bar and tow ball. If using the existing bolts the end of each bolt should protrude through the nut when tightened. If longer bolts are required they must be high tensile tow ball bolts.
3. Re-fit the electrical sockets to the lower holes of the extension plate using the M16 nuts and bolts provided for this purpose.
4. Check that the nuts are fully tightened.
5. Check the electrics to ensure that they work correctly

This product is designed to suit a range of vehicles. It is the responsibility of the person fitting the product to ensure that it is suitable for the particular application. The tow bar step is likely to project beyond the vehicles bumper and damage may be caused in the event of contact with other objects. The product should only be used as a step to aid entry to and exit from a vehicle and should never be used as a carrier.