



### **Trailer Break Away Cable**

This cable is designed to apply the trailer handbrake in the event of the trailer separating from the towing vehicle. As the trailer stops, the cable should brake away from the towing vehicle.

#### **Fitting Instructions**

The split ring on one end of the cable can be opened slightly with a flat bladed screwdriver, allowing it to be attached to the trailer braking system, usually the lowest part of the handbrake lever mechanism by passing it through a hole or loop in the steelwork.

(Check the coupling manufacturer's instructions if uncertain)

If the cable is pulled firmly towards the front of the trailer the handbrake should now operate.

#### **Instructions for Use**

When attaching the trailer to the towing vehicle, the break away cable should be uncoiled and passed through the attachment point provided, alternatively passed around the towing bracket or some other firm attachment point. The spring clip on the end of the cable should be fastened back to the cable to form a loop.

MP501 09/10

