

WYCHBOLD POLED SUN CANOPIES MP9564/ MP9565/ MP9566 USER GUIDE



Please read this user guide before attempting to set up your Poled Sun Canopy. Follow the user guide carefully and keep for future reference.

**A copy of the user guide is also available on our website
www.maypoleltd.com**

WYCHBOLD POLED SUN CANOPIES MP9564/ MP9565/ MP9566 USER GUIDE

WARNING – GENERAL SAFETY

- Not to be used in strong winds and extreme weather conditions.
- If using stepladders or a platform to set up the canopy you will be working at height & should carefully follow the stepladder / platform manufacturer's safety instructions. You should not attempt to set up this Canopy from the ladder but only to use the ladder if required to assist people on the ground.
- **DO NOT drive with this canopy attached to your vehicle.**

CARE OF YOUR CANOPY

- Allow material to dry completely before storing in the storage bag provided.
- Remove dirt with a soft sponge and warm water. DO NOT use detergent.
- DO NOT expose to sparks, flames or other sources of ignition.
- NOTE – during certain conditions moisture maybe visible on the inside of the material. This is the natural build up of condensation and should not be mistaken for leaking.

CONTENTS

Canopy x 1

Fibreglass canopy pole x 1

Corner steel pole x 2

Steel roof pole x 1 (MP9565 only)

PVC ladder pegging straps x 8 (MP9566 x 6 only)

Guy ropes x 5

Steel pegs x 15 (MP9566 x 13 only)

Carry bag x 1

WYCHBOLD POLED SUN CANOPIES MP9564/ MP9565/ MP9566 USER GUIDE

BEFORE USE

Choose a clear site that is flat. Remove any sharp objects from the pitching area which could be dangerous or potentially damage the fabric.

NOTE – MP9564 & MP9565 are suitable for an awning channel height range of 235cm – 250cm (caravan & motorhomes). MP9566 is suitable for an awning channel height range of 180cm – 210cm (campervans).

NOTE – either a 4mm or 6mm awning channel is required to fit this canopy to your vehicle.

PITCHING INSTRUCTIONS

Remove the canopy from the carry bag and place flat on the ground.

Pre attach all 8 pvc ladder pegging straps to all pegging points.



The canopy has a 4mm & 6mm dual beading sewn into it. Choose the correct beading size for your awning channel (4mm or 6mm) and slide it into the awning channel on your vehicle.



WYCHBOLD POLED SUN CANOPIES MP9564/ MP9565/ MP9566 USER GUIDE

Pre-assemble the fibreglass canopy pole and insert it into the front black sleeve. Pre-assemble both corner steel poles to the adjustable legs. Insert each end of the fibreglass pole into each corner steel pole.



Insert the metal pin at the base of the canopy into the bottom of each corner steel pole.



Extend the adjustable legs on both steel corner poles to the maximum height.

Attach the canopy to both steel corner poles using the plastic clips.



WYCHBOLD POLED SUN CANOPIES MP9564/ MP9565/ MP9566 USER GUIDE

Buckle together the sizing strap between each leg to achieve the correct spacing. Peg down both pvc ladder pegging strap closest to the vehicle and on both steel legs.

Once in position; loosely peg down the 3 guy ropes found at the front of the canopy.

For MP9565 only; pre assemble the steel roof pole and insert into the plastic roof sleeves. Once inserted; extend to its maximum length.



Once secure, peg down all remaining pvc ladder pegging straps and guy ropes. It is recommended each peg is driven fully into the ground at an angle of 45 Degrees away from the pegging point.

Tension each guy rope using the guy tensioners provided.



Technical Manager Maypole Ltd Oct 2022

Email: sales@maypoleltd.co.uk

Web: www.maypoleltd.com