



PRO VIEW TOWING MIRROR **USER GUIDE**



This user guide relates to the following Maypole Pro View Towing Mirrors:

MP8330 Flat Lens (Single Mirror)
MP8331 Convex Lens (Single Mirror)
MP8332 Flat Lens (Twin Pack)
MP8333 Convex Lens (Twin Pack)

Please read and follow this user guide and all safety instructions carefully when using this towing mirror.

Keep this user guide for future reference. When passing the towing mirror onto others be sure to also include all documentation. The user guide is also available on our website:

www.maypoleltd.com

IMPORTANT SAFETY INSTRUCTIONS

- The attachment of this towing mirror to a vehicle is safety critical and beyond the control of the manufacturer. The user must therefore ensure that the towing mirror is suitable for their vehicle and fitted correctly.
- Only ever use this product in conjunction with the components supplied.
- Thoroughly inspect the mirror and its components prior to each use. If any component is damaged, the product should not be used.
- Check all fixings prior to each journey and at regular intervals throughout to ensure fixings are fully tightened and the mirror is secure.
- It is critical that the rubber safety strap is always fitted, securely fastened and tensioned appropriately.

COMPONENTS

MP8330 & MP8331

- 1 towing mirror
- 1 set of fixing clamps
- 1 rubber safety strap



MP8332 & MP8333

- 2 towing mirrors
- 2 sets of fixing clamps
- 2 rubber safety straps
- 1 storage bag



PREPARATION OF PARTS

- 1). Slide the first bracket onto the mirror bar so that the recess will face the wing mirror when fitted.
- 2). Slide the rubber safety strap onto the mirror bar ensuring the ribbed side of the strap will be in contact with the back of the wing mirror when fitted.
- 3). Slide the second bracket onto the mirror bar so that the recess will face the wing mirror when fitted.

The correct arrangement is shown below:



FITTING THE MIRROR

- 1). Maximise the height of the gripper pads on the fixing clamp by turning the thumb wheel.
- 2). Offer the towing mirror to the wing mirror so that the recess of both clamps face the wing mirror.
- 3). Slide the clamp between the glass and the mirror body. Ensure the gripper pads grip onto the top of the mirror body as shown below:



NOTE – if the gap between the glass and mirror body is too small do not attempt to force the clamps into place as this may cause damage to the mirror glass.

4). Pass the rubber safety strap behind the body of the wing mirror and position the end of the 'L' shaped bracket between the glass and the bottom mirror body as shown below:



5). Ensure the rubber strap has sufficient tension to provide a secure fixing.

6). Adjust the mirror clamps so they are as far apart as possible. This will give better stability in use.

7). Secure the gripper pads onto the mirror body by using the thumb wheels. NOTE – do not overtighten as this could damage your mirror body.

8). Once fitted correctly check the overall security of the mirror. Adjust the mirror head for optimum rear visibility.

If your caravan is wider than your car it is a legal requirement to fit towing mirrors.

When fitted this towing mirror should allow the driver to see the road alongside and parallel to the widest part of the trailer.

The drivers field of vision should extend outwards to a width of 4m from this line 20 metres behind the driver.

III (E4) 046015

Technical Manager, Maypole Ltd, Nov 2020

Email: sales@maypoleltd.co.uk

Web: www.maypoleltd.com