



MP478 Lock is inserted into the keyhole shaped opening in a pressed steel coupling.

The key is then turned $\frac{1}{4}$ of a turn and removed.

The lock remains in the coupling and prevents the coupling handle from being operated.

The trailer cannot be hitched or unhitched.

