

## POP UP TOILET TENT MP9514 USER GUIDE



Please read this user guide before attempting to set up your Pop Up Toilet Tent. Follow the user guide carefully and keep for future reference.

A copy of the user guide is also available on our website  
[www.maypoleltd.com](http://www.maypoleltd.com)

# POP UP TOILET TENT MP9514 USER GUIDE

## **WARNING – GENERAL SAFETY**

- Not to be used in strong winds and extreme weather conditions.

## **CARE OF YOUR POP UP TOILET TENT**

- Allow material to dry completely before storing in the storage bag provided.
- Remove dirt with a soft sponge and warm water. DO NOT use detergent.
- DO NOT expose to sparks, flames or other sources of ignition.
- NOTE – during certain conditions moisture maybe visible on the inside of the material. This is the natural build up of condensation and should not be mistaken for leaking.

## **CONTENTS**

Pop Up Toilet Tent x 1

Guy Ropes x 4

Steel Pegs x 8

Carry Bag x 1

## **BEFORE USE**

Choose a clear site that is flat and if possible sheltered from the wind. Remove any sharp objects from the pitching area which could be dangerous or potentially damage the fabric.

## POP UP TOILET TENT MP9514 USER GUIDE

### PITCHING INSTRUCTIONS

Remove the pop up toilet tent from the carry bag.

Place flat on the ground (FIG 1).

Holding the tent upright; pop out the two side panels to create the tent shape (FIG 2).

FIG 1



FIG 2



Once you have selected a suitable location to pitch your tent; peg down each corner. Ensure the tent is taut when pegging so it forms the correct shape.

The front door can be zipped closed or rolled and held by toggles.

Tie a guy rope around each of the 4 guy points and peg out each guy rope securely.

It is recommended each peg is driven fully into the ground at an angle of 45 Degrees away from the pegging point. Tension each guy rope using the guy adjusters (FIG 3).

FIG 3



## POP UP TOILET TENT MP9514 USER GUIDE

### PACKING AWAY YOUR POP UP TOILET TENT

Remove all guy ropes and pegs from each corner.

Push in the two side panels and place flat on the ground with the front (door) panel at the top.

Holding the tent from the base; place the top of the tent into the ground (FIG 4). Fold the tent to the point shown in FIG 5.

FIG 4



FIG 5



Twist the 2 bottom corners and fold them into the front door panel on the floor (FIG 6). The tent should naturally fold into a circular shape (FIG 7). Compact the tent into a tight circular shape ensuring it is small enough to re-pack into the storage bag.

FIG 6



FIG 7





## POP UP TOILET TENT MP9514 USER GUIDE

A QR code to a video showing how to pack away the toilet tent can be found below:



*S. J. Cole*

Technical Manager Maypole Ltd November 2020

Email: [sales@maypoleltd.co.uk](mailto:sales@maypoleltd.co.uk)

Web: [www.maypoleltd.com](http://www.maypoleltd.com)