


COMBINATION CODE INSTRUCTIONS



Product must be unlocked with the correct code before a new code can be set. Initial code is set "00000".



Remove password setting cover



Twist the reset button to the "SET" position



Set the desired new password



Twist the reset button back to its original position and replace the password setting cover

IMPORTANT: RECORD YOUR NEW CODE IMMEDIATELY. IF THE CODE IS LOST, THE LOCK CANNOT BE OPENED

Maypole Ltd. 162 Clapgate Lane Birmingham B32 3DE UK
Maypole Touring Ireland Ltd, 40 Mespil Road, Dublin 4,
D04 C2N4, Ireland
E: sales@maypoleltd.co.uk W: www.maypoleltd.com