

‘STONELEIGH’ POLED PORCH AWNING 390CM MP9554 USER GUIDE



**Please read this user guide before attempting to set up your Porch Awning.
Follow the user guide carefully and keep for future reference.**

**A copy of the user guide is also available on our website
www.maypoleltd.com**

‘STONELEIGH’ POLED PORCH AWNING 390CM MP9554 USER GUIDE

WARNING – GENERAL SAFETY

- Not to be used in strong winds and extreme weather conditions.
- If using stepladders or a platform to set up the Porch Awning you will be working at height & should carefully follow the stepladder / platform manufacturer’s safety instructions. You should not attempt to set up this Porch Awning from the ladder but only to use the ladder if required to assist people on the ground.
- **DO NOT drive with this awning attached to your vehicle.**

CARE OF YOUR PORCH AWNING

- Allow material to dry completely before storing in the storage bag provided.
- Remove dirt with a soft sponge and warm water. DO NOT use detergent.
- DO NOT expose to sparks, flames or other sources of ignition.
- NOTE – during certain conditions moisture maybe visible on the inside of the material. This is the natural build up of condensation and should not be mistaken for leaking.

CONTENTS

Porch Awning x 1

Draught Skirt x 1

Fibreglass roof pole x 1

Corner steel pole x 2

Steel rear padded poles x 2

Front canopy poles x 2

Steel pegs x 21

Guy ropes x 7

Carry bag x 1

‘STONELEIGH’ POLED PORCH AWNING 390CM MP9554 USER GUIDE

BEFORE USE

Choose a clear site that is flat. Remove any sharp objects from the pitching area which could be dangerous or potentially damage the fabric.

NOTE – this Porch Awning is suitable for vehicles with an awning channel height range of 235cm – 250cm.

NOTE – either a 4mm or 6mm awning channel is required to fit this Porch Awning to your vehicle.

PITCHING INSTRUCTIONS

Remove the Porch Awning from the carry bag and place flat on the ground. Ensure the dual beading faces the vehicle.

The awning has a 4mm & 6mm dual beading sewn into it. Choose the correct beading size for your awning channel and slide it into the awning channel on your vehicle.




‘STONELEIGH’ POLED PORCH AWNING 390CM MP9554 USER GUIDE

Insert the fibreglass roof pole into the front sleeve. Pre-assemble both corner steel poles to the adjustable legs. Insert each end of the fibreglass roof pole into both corner steel poles.



Attach the canopy to the steel poles using the plastic clips. Extend the adjustable legs on the steel corner poles to the maximum height.



Insert the metal pins at the base of the awning into the bottom of each corner steel pole.



‘STONELEIGH’ POLED PORCH AWNING 390CM MP9554 USER GUIDE

Buckle together the sizing strap between each leg to achieve the correct spacing. Peg down each leg at the base and all pegging points to form the shape below:



Once in position; peg down the 3 guy ropes found at the front of the awning and fully tension using the adjusters provided.



It is recommended each peg is driven fully into the ground at an angle of 45 Degrees away from the pegging point.

‘STONELEIGH’ POLED PORCH AWNING 390CM MP9554 USER GUIDE

Steel rear padded poles are included to enable the awning to be firmly held against the vehicle. Pre-assemble the steel poles and secure to the rear corner foam pads with the velco attachments. The poles can be adjusted to suit the height of the vehicle.



To pitch the front canopy; pre assemble the steel canopy poles and attach the plastic feet to the base. Extend the front door and insert the top spike on each pole into the corner eyelets of the front door. Peg down the plastic feet of the canopy poles. Attach guy ropes to the top of both canopy poles. Peg down the guy ropes and fully tension once in position.



'STONELEIGH' POLED PORCH AWNING 390CM MP9554 USER GUIDE

To attach the draught skirt; insert the beading into the bottom awning channel on the vehicle and slide to the desired position.



S. J. O'Leary

Technical Manager Maypole Ltd Oct 2022

Email: sales@maypoleltd.co.uk

Web: www.maypoleltd.com