

‘STONELEIGH’ AIR PORCH AWNING 390CM MP9555 USER GUIDE



Please read this user guide before attempting to set up your Air Porch Awning. Follow the user guide carefully and keep for future reference.

**A copy of the user guide is also available on our website
www.maypoleltd.com**

‘STONELEIGH’ AIR PORCH AWNING 390CM MP9555 USER GUIDE

WARNING – GENERAL SAFETY

- Not to be used in strong winds and extreme weather conditions.
- If using stepladders or a platform to set up the Air Porch Awning you will be working at height & should carefully follow the stepladder / platform manufacturer’s safety instructions. You should not attempt to set up this Air Porch Awning from the ladder but only to use the ladder if required to assist people on the ground.
- **DO NOT drive with this awning attached to your vehicle.**

CARE OF YOUR AIR PORCH AWNING

- Allow material to dry completely before storing in the storage bag provided.
- Remove dirt with a soft sponge and warm water. DO NOT use detergent.
- DO NOT expose to sparks, flames or other sources of ignition.
- NOTE – during certain conditions moisture maybe visible on the inside of the material. This is the natural build up of condensation and should not be mistaken for leaking.

CONTENTS

Porch Awning x 1

Draught skirt x 1

Steel rear padded poles x 2

Front canopy poles x 2

Air roof poles x 3

Steel pegs x 23

Guy ropes x 4

Webbing straps x 3

Hand pump x 1

Carry bag x 1

‘STONELEIGH’ AIR PORCH AWNING 390CM MP9555 USER GUIDE

BEFORE USE

Choose a clear site that is flat. Remove any sharp objects from the pitching area which could be dangerous or potentially damage the fabric or puncture the air tubes.

NOTE – this Air Porch Awning is suitable for vehicles with an awning channel height range of 235cm – 250cm.

NOTE – either a 4mm or 6mm awning channel is required to fit this Air Porch Awning to your vehicle.

PITCHING INSTRUCTIONS

Remove the Porch Awning from the carry bag and place flat on the ground. Ensure the dual beading faces the vehicle.

The awning has a 4mm & 6mm dual beading sewn into it. Choose the correct beading size for your awning channel and slide it into the awning channel on your vehicle.



'STONELEIGH' AIR PORCH AWNING 390CM MP9555 USER GUIDE

Locate the air valve on right hand side of the awning and unscrew the top cap.



Air Valve

Connect the large adaptor to the hand pump. Insert the adaptor into the top cap on the valve. Inflate the air beam to approx. 6-7 PSI. Once inflated; remove the adaptor from the valve and securely tighten the top cap. **WARNING: WHEN INFLATING; DO NOT EXCEED A PRESSURE OF OVER 7 PSI. IN STRONG SUNLIGHT & IN HOT TEMPERATURES REDUCE THE PRESSURE TO 4-5 PSI.**



The porch awning should now be able to support itself.

‘STONELEIGH’ AIR PORCH AWNING 390CM MP9555 USER GUIDE

Inflate the 3 air roof tubes to 6-7PSI. Attach each roof tube to the velcro pads in between the vehicle and the main front air beam.



Buckle together the sizing strap between each leg to achieve the correct spacing. Peg down each leg at the base and all pegging points to form the shape below:



Once in position; peg down the 4 guy ropes and 3 webbing straps found at the front of the awning and fully tension using the adjusters provided.



It is recommended each peg is driven fully into the ground at an angle of 45 Degrees away from the pegging point.

‘STONELEIGH’ AIR PORCH AWNING 390CM MP9555 USER GUIDE

Steel rear padded poles are included to enable the awning to be firmly held against the vehicle. Pre-assemble the steel poles and secure to the rear corner pads with the velco attachments. The poles can be adjusted to suit the height of the vehicle.



To pitch the front canopy; pre assemble the steel canopy poles and attach the plastic feet to the base. Extend the front door and insert the top spike on each pole into the corner eyelets of the front door. Peg down the plastic feet of the canopy poles. Attach guy ropes to the top of both canopy poles. Peg down the guy ropes and fully tension once in position.



‘STONELEIGH’ AIR PORCH AWNING 390CM MP9555 USER GUIDE

To attach the draught skirt; insert the beading into the bottom awning channel on the vehicle and slide to the desired position.



To deflate the air tube unscrew the bottom cap on the valve and the air will be released.
WARNING – Be aware of sudden loud noise caused by air escaping when deflating.

Signature

Technical Manager Maypole Ltd Oct 2022

Email: sales@maypoleltd.co.uk

Web: www.maypoleltd.com