

## **‘DRAYTON’ POLED DRIVEAWAY AWNING MP9558 USER GUIDE**



**Please read this user guide before attempting to set up your Driveway Awning. Follow the user guide carefully and keep for future reference.**

**A copy of the user guide is also available on our website  
[www.maypoleltd.com](http://www.maypoleltd.com)**

# **‘DRAYTON’ POLED DRIVEAWAY AWNING MP9558 USER GUIDE**

## **WARNING – GENERAL SAFETY**

- Not to be used in strong winds and extreme weather conditions.
- If using stepladders or a platform to set up the Driveway Awning you will be working at height & should carefully follow the stepladder / platform manufacturer’s safety instructions. You should not attempt to set up this Driveway Awning from the ladder but only to use the ladder if required to assist people on the ground.
- **DO NOT drive with this awning attached to your vehicle.**

## **CARE OF YOUR DRIVEAWAY AWNING**

- Allow material to dry completely before storing in the storage bag provided.
- Remove dirt with a soft sponge and warm water. DO NOT use detergent.
- DO NOT expose to sparks, flames or other sources of ignition.
- NOTE – during certain conditions moisture maybe visible on the inside of the material. This is the natural build up of condensation and should not be mistaken for leaking.

## **CONTENTS**

Driveway awning x 1

Fibreglass pole x 2

Steel roof bars x 2

Ground sheet x 1

PVC ladder pegging straps x 4

Guy ropes x 9

Steel pegs x 23

Carry bag x 1

## **‘DRAYTON’ POLED DRIVEAWAY AWNING MP9558 USER GUIDE**

### **BEFORE USE**

Choose a clear site that is flat. Remove any sharp objects from the pitching area which could be dangerous or potentially damage the fabric.

NOTE – this Driveway Awning is suitable for vehicles with an awning channel height range of 180cm – 210cm.

NOTE – either a 4mm or 6mm awning channel is required to fit this Driveway Awning to your vehicle.

### **PITCHING INSTRUCTIONS**

Remove the Awning from the carry bag and place flat on the ground. Ensure the dual beading faces the vehicle.

The awning has a 4mm & 6mm dual beading sewn into it. Choose the correct beading size for your awning channel and slide it into the awning channel on your vehicle.



## **‘DRAYTON’ POLED DRIVEAWAY AWNING MP9558 USER GUIDE**

Pre-assemble both fibreglass poles.

Insert the first fibreglass pole into the black sleeve found on the side of the awning. Secure the end of the pole into the eyelet at the base. Repeat with the second fibreglass pole.



Peg down the pegging points at the rear of the tunnel closest to the vehicle. Peg down all pegging points found at the side and front of the awning to achieve the shape below:



## **‘DRAYTON’ POLED DRIVEAWAY AWNING MP9558 USER GUIDE**

Pre assemble the 2 steel roof bars. Insert each end of the roof bar into the corner roof pockets. Extend the roof bar to its maximum length. Repeat with the second roof bar.



Peg down all the guy ropes and fully tension using the guy adjusters once in position.



*S. Cole*

Technical Manager Maypole Ltd Oct 2022

Email: [sales@maypoleltd.co.uk](mailto:sales@maypoleltd.co.uk)

Web: [www.maypoleltd.com](http://www.maypoleltd.com)