

## MP9575 'ROMSLEY' SUN CANOPY - USER GUIDE



Please read & follow this user guide & all safety instructions carefully when using this product.

Keep the user guide for future reference. When passing the product onto others be sure to include all documentation. The user guide is also available on our website: [www.maypoleltd.com](http://www.maypoleltd.com)

# MP9575 'ROMSLEY' SUN CANOPY - USER GUIDE

## GENERAL SAFETY

- Not to be used in strong winds and extreme weather conditions.
- If using stepladders or a platform to set up the Sun Canopy you will be working at height & should carefully follow the stepladder / platform manufacturer's safety instructions. You should not attempt to set up this Sun Canopy from the ladder but only to use the ladder if required to assist people on the ground.
- **DO NOT drive with this Sun Canopy attached to your vehicle.**

## CARE OF YOUR SUNCANOPY

- Allow material to dry completely before storing in the storage bag provided.
- Remove dirt with a soft sponge and warm water. DO NOT use detergent.
- DO NOT expose to sparks, flames or other sources of ignition.
- NOTE – during certain conditions moisture maybe visible on the inside of the material. This is the natural build up of condensation and should not be mistaken for leaking.

## CONTENTS

Sun Canopy x 1

Fibreglass Pole x 1

Extendable Steel Roof Pole x 1

Guy ropes x 2

Steel Pegs x 6

Carry Bag x 1

## BEFORE USE

Choose a clear site that is flat. Remove any sharp objects from the pitching area which could be dangerous or potentially damage the fabric.

NOTE – this Sun Canopy is suitable for vehicles with an awning channel height range of 180cm – 250cm.

NOTE – either a 4mm or 6mm awning channel is required to fit this Sun Canopy to your vehicle.

## MP9575 'ROMSLEY' SUN CANOPY - USER GUIDE

### PITCHING INSTRUCTIONS

Remove the Sun Canopy from the carry bag and place flat on the ground. Ensure the dual beading faces the vehicle.

The suncanopy has a 4mm & 6mm dual beading sewn into it. Choose the correct beading size for your awning channel (4mm or 6mm) and slide it into the awning channel on your vehicle.



Pre assemble the fibreglass pole and insert it into the sleeve at the front of the canopy. Insert both metal pins at the base of the canopy into the bottom of the fibreglass pole:





## MP9575 'ROMSLEY' SUN CANOPY - USER GUIDE

Adjust the fabric so it is evenly distributed on the fibreglass pole.

Manoeuvre the canopy so it is in the desired position on the vehicle.

Attach all plastic clips to both sides of the fibreglass poles.



Ensure the sizing strap between the fibreglass pole is extended to the maximum length to achieve the correct width. Once in position; insert steel pegs through the metal rings at the base of the fibreglass pole and peg down the eyelets on the sizing strap:



## MP9575 'ROMSLEY' SUN CANOPY - USER GUIDE

Insert the extendable steel roof pole into both ends of the PVC pockets found in the middle of the canopy. Ensure it is fully tensioned. This allows rain to drain off and provides extra shape and support in adverse weather conditions.



Finally; peg down both triangular guy ropes on each corner.



It is recommended each peg is driven fully into the ground at an angle of 45 degrees away from the pegging point. Tension each guy rope using the guy tensioners provided:



*Signature*

Technical Manager Maypole Ltd Nov 2024

Email: [sales@maypoleltd.co.uk](mailto:sales@maypoleltd.co.uk)

Web: [www.maypoleltd.com](http://www.maypoleltd.com)

**Maypole Ltd, 162 Clapgate Lane, Birmingham, B32 3DE, UK**

**Maypole Touring Ireland Ltd, 40 Mespil Road, Dublin 4, D04 C2N4, Ireland**